



SPECTRUM
INSTRUMENTATION

Perfect fit – modular designed solutions



SCAPP Package

**Spectrum CUDA Access
for Parallel Programming**

for M4i, M2p and M5i cards

Latest revision: 14. August 2025

Digitizers | Transient Recorders | Arbitrary Waveform Generators | Digital Waveform Acquisition Cards
for PCI Express, PXI Express and LXI / Ethernet

(c) SPECTRUM INSTRUMENTATION GMBH
AHRENSFELDER WEG 13-17, 22927 GROSSHANSDORF, GERMANY

SBench, digitizerNETBOX, generatorNETBOX and hybridNETBOX are registered trademarks of Spectrum Instrumentation GmbH.
Microsoft, Visual C++, Windows, Windows 98, Windows NT, Windows 2000, Windows XP, Windows Vista, Windows 7, Windows 8, Windows 10, Windows 11 and Windows Server are trademarks/registered trademarks of Microsoft Corporation.
LabVIEW, DASyLab, Diadem and LabWindows/CVI are trademarks/registered trademarks of National Instruments Corporation.
MATLAB is a trademark/registered trademark of The Mathworks, Inc.
Delphi and C++Builder are trademarks or registered trademarks of Embarcadero Technologies, Inc.
Keysight VEE, VEE Pro and VEE OneLab are trademarks/registered trademarks of Keysight Technologies, Inc.
FlexPro is a registered trademark of Weisang GmbH & Co. KG.
PCIe, PCI Express, PCI-X and PCI-SIG are trademarks of PCI-SIG.
PICMG and CompactPCI are trademarks of the PCI Industrial Computation Manufacturers Group.
PXI is a trademark of the PXI Systems Alliance.
LXI is a registered trademark of the LXI Consortium.
IVI is a registered trademark of the IVI Foundation.
Oracle and Java are registered trademarks of Oracle and/or its affiliates.
Python is a trademark/registered trademark of Python Software Foundation.
Julia is a trademark/registered trademark of Julia Computing, Inc.
Intel and Intel Core i3, Core i5, Core i7, Core i9 and Xeon are trademarks and/or registered trademarks of Intel Corporation.
AMD, Opteron, Sempron, Phenom, FX, Ryzen and EPYC are trademarks and/or registered trademarks of Advanced Micro Devices.
Arm is a trademark or registered trademark of Arm Limited (or its subsidiaries).
NVIDIA, CUDA, GeForce, Quadro, Tesla and Jetson are trademarks and/or registered trademarks of NVIDIA Corporation.

Table of Contents

Table of Contents	3
SCAPP Option	4
The SCAPP Package	4
Requirements	4
Supported Spectrum Products.....	4
Preparation	5
Install CUDA Toolkit.....	5
Build the Nvidia kernel driver module	5
Compiling a CUDA RDMA enabled kernel driver module.....	5
Programming	6
Setup of Spectrum Device.....	6
Definition of the transfer buffer	6
GPU	6
Data flow and Control flow	7
Examples	7
Python support for SCAPP and CUDA	7
Usefull Links	7

SCAPP Option

Spectrum's CUDA Access for Parallel Processing

Modern GPUs (Graphic Processing Units) are designed to handle a large number of parallel operations. While a CPU offers only a few cores for parallel calculations, a GPU can offer thousands of cores. This computing capabilities can be used for calculations using the Nvidia CUDA interface.

Since bus bandwidth and CPU power are often a bottleneck in calculations, CUDA Remote Direct

Memory Access (RDMA) can be used to directly transfer data from/to a Spectrum Digitizer/Generator to/from a GPU card for processing, thus avoiding the transfer of raw data to the host memory and benefiting from the computational power of the GPU.



The SCAPP Package

The SCAPP package opens up a CUDA-based GPU for parallel measurement data processing by giving a method of direct data transfer from Spectrum card to GPU accompanied by some easy-to-use programming examples that show the usage of the parallel processing. The examples also show how the direct data transfer is set up and handled and how the GPU measurement results are transferred back into the PC system for further analysis, storage or display.

Requirements

Motherboard with two free PCIe slots for Spectrum Digitizer and Nvidia GPU card. Please make sure that both slots fit the maximum PCIe lane and generation of the card to receive optimum performance

- Linux based operating system. RDMA on Windows is NOT supported.
- Spectrum Digitizer or Arbitrary Generator with enabled SCAPP option
- Nvidia Quadro or Tesla card with CUDA compute capability 5.0 or higher. GeForce cards are NOT supported, even if their CUDA compute capability is 5.0 or higher.
A list of the GPUs and their CUDA compute capabilities can be found here: <https://developer.nvidia.com/cuda-gpus>.
- Nvidia Toolkit
- Granted access to Spectrum kernel driver sources and SCAPP examples

SCAPP and Windows: Due to restrictions of the Nvidia driver it is not possible to do remote data transfer (RDMA) between a PCIe card and a Nvidia GPU using any Windows operating system. The calculation on the GPU itself can be used under Windows and Linux but from a Windows host, the data has to be transferred using one DMA transfer from Digitizer to PC and a second DMA transfer from PC to GPU.



Supported Spectrum Products

All M5i, M4i and M2p products are supported by the SCAPP option. Please note that the integrated RDMA is a function of the kernel driver and is therefore available for all products of these series of PCIe cards.

Preparation

If you're using an NVidia Jetson, then the CUDA Toolkit and NVidia kernel driver are automatically installed, when setting up the Jetson. In that case, you can skip the first two steps.

Install CUDA Toolkit

Download the Nvidia CUDA Toolkit and install it as described here:
<http://docs.nvidia.com/cuda/cuda-installation-guide-linux/index.html>.

Build the Nvidia kernel driver module

Download the Nvidia driver from here: <http://www.nvidia.com/Download/index.aspx>.

Extract it on a command line using.

```
./NVIDIA-Linux-x86_64-<version>.run -x
```

Navigate to the output directory:

```
cd <output directory>/kernel/
```

Build the Nvidia kernel driver module:

```
make module
```

This will create the nvidia.ko kernel module and a Module.symvers file that is needed in the next step.

Compiling a CUDA RDMA enabled kernel driver module

To enable CUDA RDMA capability in the kernel driver module it needs to be linked to the proprietary Nvidia kernel driver module.

In the Spectrum kernel driver makefile uncomment the line that contains „NVIDIA_DRV_SRC :=“ by removing the # at the beginning of the line. There are multiple options, for different platforms (e.g. Intel/AMD x86, Jetson Xavier, Jetson Orin). Uncomment the option that suits your platform. Then compile the Spectrum kernel module as described in the Readme file. The Makefile will add the necessary steps to link against the Nvidia kernel module.

After the kernel module has been loaded successfully you can run dmesg to check if RDMA support has been enabled correctly. The Spectrum kernel driver module is called spcm4 and should output „Driver supports CUDA RDMA“:

```
[ 2.185902] spcm4: Spectrum 64 bit driver loaded. Version 1.20 build 13926.
[ 2.185903] spcm4: Driver supports CUDA RDMA.
[ 2.185935] spcm4_cards 0000:02:00.0: enabling device (0000 -> 0002)
[ 2.186069] spcm4: /dev/spcm0: M4i.44xx-x8
```

To check if the SCAPP option is available on the card you can read the SPC_PCIFEATURES register from your program:

Register	Value	Direction	Description
SPC_PCIFEATURES	2120	read	PCI feature register. Holds the installed features and options as a bitfield. The read value must be masked out with one of the masks below to get information about one certain feature.
SPCM_FEAT_SCAPP	20000h		Support for the SCAPP option allowing CUDA RDMA access to/from supported graphics cards for GPU calculations.

Programming

Setup of Spectrum Device

Setup of the Spectrum Digitizer for RDMA differs only slightly from a setup without RDMA. Like in the C/C++ examples the `spcm_dwSetParam_i32 ()` function and its friends are used to program the Spectrum Digitizer.

This manual only explains the additional information needed to run the SCAPP examples. Please refer to the standard hardware manual for a detailed description of the functions and setup registers of the driver and the hardware.



To use the direct data transfer from Digitizer to GPU or GPU to AWG the same function for data transfer setup `spcm_dwDefTransfer_i64 ()` is used as already explained in the hardware manual:

Definition of the transfer buffer

Before any data transfer can start it is necessary to define the transfer buffer with all its details. The definition of the buffer is done with the `spcm_dwDefTransfer` function as explained in an earlier chapter.

```
uint32_stdcall spcm_dwDefTransfer_i64 (// Defines the transfer buffer by using 64 bit unsigned integer values
    drv_handle hDevice, // handle to an already opened device
    uint32 dwBufType, // type of the buffer to define as listed below under SPCM_BUF_XXXX
    uint32 dwDirection, // the transfer direction as defined below
    uint32 dwNotifySize, // number of bytes after which an event is sent (0=end of transfer)
    void* pvDataBuffer, // pointer to the data buffer
    uint64 qwBrdOffs, // offset for transfer in board memory
    uint64 qwTransferLen); // buffer length
```

This function is used to define buffers for standard sample data transfer as well as for extra data transfer for additional ABA or timestamp information. The `dwBufType` parameter must be the following:

SPCM_BUF_DATA	1000	Buffer is used for transfer of standard sample data
---------------	------	---

The `dwDirection` parameter defines the direction of the following data transfer:

SPCM_DIR_PCTOCARD	0	Transfer is done from PC memory to on-board memory of card.
SPCM_DIR_CARDTOPC	1	Transfer is done from card on-board memory to PC memory.
SPCM_DIR_CARDTOGPU	2	RDMA transfer from card memory to GPU memory, SCAPP option needed, Linux only, Digitizer only
SPCM_DIR_GPUCARD	3	RDMA transfer from GPU memory to card memory, SCAPP option needed, Linux only, AWG only

The direction parameter `SPCM_DIR_CARDTOGPU` sets up the DMA engine on the Spectrum Digitizer to transfer the data from the Digitizer into the buffer on the GPU instead of transferring it to the host memory. If `CARDTOGPU` is used it is required to use a buffer on the GPU which can be allocated using the CUDA function `cudaMalloc ()`.

The corresponding direction value for transfer from the GPU memory to a Spectrum AWG is `SPCM_DIR_GPUCARD`.

GPU

CUDA uses different functions to allocate memory:

- `cudaMalloc ()` allocates a buffer on the GPU
 - `cudaMallocHost ()` allocates a buffer on the host (in the PC memory), similar to the `malloc ()` function in standard C.
- Data can be copied between a buffer on the GPU and a buffer on the host using the `cudaMemcpy ()` function. This function uses an interface similar to the standard C `memcpy ()` function, but with an additional parameter that defines the direction of the data transfer.

The `CU_POINTER_ATTRIBUTE_SYNC_MEMOPS` flag needs to be enabled if a GPU buffer should be used for RDMA:

```
unsigned int dwFlag = 1;
cuPointerSetAttribute (&dwFlag, CU_POINTER_ATTRIBUTE_SYNC_MEMOPS, (CUdeviceptr)pvDMABuffer_gpu);
```

Spectrum's convenience function `pvGetRDMABuffer ()` which is part of the RDMA examples checks if the requested CUDA device matches the necessary requirements. Then it allocates a buffer on the GPU, sets it up for RDMA transfer and returns it to the user program.

