


MX.70xx - 32 bit fast digital I/O with TTL levels

- PXI 3U / CompactPCI 3U format
- 1, 2, 4, 8, 16 bit or 32 bit digital I/O
- 1 kS/s up to 125 MS/s at 16 bit
- 1 kS/s up to 60 MS/s at 32 bit
- 110 Ohm input impedance selectable
- Inputs 3.3 V and 5 V TTL compatible
- Outputs 3.3 V TTL compatible
- Up to 128 MByte memory
- FIFO mode for input and output
- Pattern/Edge/Pulsewidth trigger
- Synchronization possible
- Software SBench for Windows included
- Software SBench for Linux included

Product range overview

Hardware block diagram



Software programmable parameters

sampling rate	1 kS/s to max sampling rate, external clock, ref clock, PXI clock
Direction	Input/Output for each module
Input impedance	110 Ohm / 50 kOhm for each channel
Clock mode	internal PLL, internal quartz, external, external divided, external reference clock, PXI reference clock
Clock impedance	110 Ohm / 50 kOhm
Trigger impedance	110 Ohm / 50 kOhm
Trigger pulsewidth	1 to 256 samples in steps of 1
Trigger mode	Pattern and mask, edge, external TTL, software, PXI Line[50], PXI Startrigger
Pattern and mask	32 bit / 64 bit wide: 0 pattern, 1 patterm, don't care or edge
Memory depth	32 up to installed memory in steps of 32
Posttrigger	32 up to 128 M in steps of 32
Multiple Recording segmentsize	32 up to installed memory / 2 in steps of 32

Application examples

Semiconductor test	Production test	Pattern generator
A/D data acquisition	Logic analyser	Pattern recognition

Model	I-4 bit	ă bit	I O DIT	32 bit	
MX.7005	125 MS/s	125 MS/s	125 MS/s		
MX.7010		125 MS/s	125 MS/s		
MX.7011		125 MS/s	125 MS/s	60 MS/s	

Software/Drivers

....

A large number of drivers and examples are delivered with the board or are available as an option:

- Windows NT/2000 32 bit drivers
- Windows XP/Vista/7/8/10, 32 and 64 bit driver
- Linux 32bit and 64bit drivers
- SBench 6.x Base version for Windows and Linux (recording only)
- Microsoft Visual C++ examples
- Borland Delphi examples
- Microsoft Visual Basic & Excel examples
- Python examples
- LabWindows/CVI examples
- LabVIEW drivers and examples
- MATLAB drivers and examples
- Other 3rd party drivers (e.g. VEE,DASYLab) are partly available upon request

General Information

The MX.70xx series of fast digital I/O boards offer a resolution between 1 bit and 32 bit with a maximum sampling rate of 125 MS/s (60 MS/s). The channels of the board can be either programmed for input or output. The on-board memory of up to 128 MByte can be completely used for recording or replaying digital data. Alternatively the MX.70xx can be used in FIFO mode. Then data is transferred on-line to PC memory or hard disk. The internal standard synchronisation bus allows synchronisation of several MX.xxxx boards. Therefore the MX.70xx board can be used as an enlargement to analogue boards.

Possibilities and options

<u>PXI bus</u>

The PXI bus (PCI eXtension for instrumentation) offers a variety of additional normed possibilities for synchronising different components in one system. It is possible to connect several Spectrum cards with each other as well as to connect a Spectrum card with cards of other manufacturers.

PXI reference clock

The card is able to use the 10 MHz reference clock that is supplied by the PXI system. Enabled by software the PXI reference clock is feeded in the on-board PLL. This feature allows the cards to run with a fixed phase relation.

PXI trigger

The Spectrum cards support star trigger as well as the PXI trigger bus. using a simple software commend one or more trigger lines can be used as trigger source. This feature allows the easy setup of OR connected triggers from different cards.

FIFO mode

The FIFO mode is designed for continuous data transfer between measurement board and PC memory (up to 100 MB /s) or hard disk (up to 50 MB/s). The control of the data stream is done automatically by the driver on interrupt request.


Pattern trigger

For every bit of the digital input the pattern trigger defines individually the expected level or sets the bit to "don't care". In combination with pulsewidth counter and edge detection the pattern trigger could be used to recognise a huge variety of trigger events.

External trigger I/O

All instruments can be triggered using an external TTL signal. It's possible to use positive or negative edge also in combination with a programmable pulse width. An internally recognised trigger event can - when activated by software - be routed to the trigger connector to start external instruments.

Multiple Recording



The Multiple Recording mode allows the recording of several trigger events without restarting the hardware. With this option very fast repetition rates can be achieved. The on-board memory is divided in several segments of same size. Each of them is filled with data if a trigger event occurs.

Multiple Replay

The Multiple Replay mode allows the fast output generation on several trigger events without restarting the hardware. With this option very fast repetition rates can be achieved. The on-board memory is divided into several segments of the same size. Each segment can contain different data which will then be played with the occurrence of each trigger event.

Gated Sampling

The Gated Sampling mode allows data recording controlled by an external gate signal. Data is only recorded if the gate signal has a programmed level.


Gated Replay

The Gated Sampling mode allows data replay controlled by an external gate signal. Data is only replayed if the gate signal has attained a programmed level.

External clock I/O

Using a dedicated connector a sampling clock can be fed in from an external system. It's also possible to output the internally used sampling clock to synchronise external equipment to this clock.

Reference clock



The option to use a precise external reference clock (typically 10 MHz) is necessary to synchronize the instrument for high-quality measurements with external equipment (like a signal source). It's also possible to enhance the stability of the sampling clock in this way. The driver automatically generates the requested sampling clock from the fed in reference clock.

Singleshot output

When singleshot output is activated the data of the on-board memory is played exactly one time. The trigger source can be either one of the external trigger inputs or the software trigger. After the first trigger additional trigger events will be ignored.


Continuous output

When continuous output is activated the data of the on-board memory is replayed continuously until a stop command is executed. As trigger source one can use the external TTL trigger or the software trigger.

1-4 bits mode

On the model 7005 it is also possible to use just 1, 2 or 4 bits for acquisition or replay. In 1 bit mode the 8 times higher memory is then available, at 2 bits mode it is 4 times higher and at 4 bits mode it is double. This enlarges the recording/replay time in on-board memory and it reduces the transfer rate when using FIFO mode. The data is stacked internally to 8 bit samples. Therefore all information on memory/segment/pre and posttrigger sizes and steps can be up to 8 times higher.

SBench 6



A base license of SBench 6, the easy-to-use graphical operating software for Spectrum cards, is included in the delivery. The base license makes it is possible to test the card, display acquired data and make some basic measurements. It's a valuable tool for checking the card's performance and assisting with the unit's initial setup. The cards also come with a demo license for the SBench 6 professional version. This license gives the user the opportunity to test the additional features of the professional version with their hardware. The professional version contains several advanced measurement functions, such as FFTs and X/Y display, import and export utilities as well as support for all acquisition modes including data streaming. Data streaming allows the cards to continuously acquire data and transfer it directly to the PC RAM or hard disk. SBench 6 has been optimized to handle data files of several GBytes. SBench 6 runs under Windows as well as Linux (KDE, GNOME and Unity) operating systems. A test version of SBench 6 can be downloaded di-

rectly over the internet and can run the professional version in a simulation mode without any hardware installed. Existing customers can also request a demo license for the professional version from Spectrum. More details on SBench 6 can be found in the SBench 6 data sheet.


Technical Datal

Internal samplerate External samplerate Input impedance 110 Ohm termination voltage Signal level (data, trigger, clock)	1 kS/s up to 12 DC up to 125 A 110 Ohm / 50 2.5V 3.3 V/ 5 V TTL	AS/s kOhm 1	5 pF				Dimension Width (MX.7005, MX.7010) Width (MX.7011) Connector Operating temperature	160mm x 233mm (Standard 3U) 1 slot 2 slots 40 pole half pitch (Hirose FX2 series) 0°C to 50°C
Data input current sink (no termination) Clock / trigger input current sink (no termination)	0.0 V -1.0 μA ± 1.0 μA	3.3 V +1.0 µA		5.0 V +20.0	μA		Storage temperature Humidity MTBF	-10°C to 70°C 10% to 90% 200000 hours
Multi: Trigger to 1st sample delay Multi: Recovery time	fixed < 20 samples (* 32 bit	16 - 64 bit) 16 bit 8	bit	4 bit	2 bit	1 bit		
ext. Trigger accuracy (samples) int. Trigger accuracy (samples)	1	1 2 1 2		4 4	8 8	16 16		
Trigger input:Standard TTL level	High: 2.0	> level < 0 V > level < Jse must be	5.5 V		k period		ck input: Standard TTL level	Low: -0.5 V > level < 0.8 V High: 2.0 V > level < 5.5 V Rising edge. Duty cycle: 50% ± 5%
Trigger output	Low < 0.4 High > 2.	TTL, capabl 4 V (@ 20 m 4 V (@ -20 tive edge aft	nA, max mA, ma	x 64 m/ ax -48 r	4) mA)		ck output	Standard TTL, capable of driving 50 Ohm Low < 0.4 V (@ 20 mA, max 64 mA) High > 2.4 V (@ -20 mA, max -48 mA)

Power consumption (maximum value)	Full speed				
	+3,3 V	+5 V	+12 V	-12 V	
MX.7005 (16 bit output @ 125 MS/s in 110 Ohm)	1.18 A (3.9 W)	0.81 A (4.1 W)	0 A	0 A	
MX.7010 (16 bit output @ 125 MS/s in 110 Ohm)	1.18 A (3.9 W)	0.81 A (4.1 W)	0 A	0 A	
MX.7011 (32 bit output @ 60 MS/s in 110 Ohm)	1.70 A (5.6 W)	0.81 A (4.1 W)	0 A	0 A	

For detailed information on the different modes for external clockingplease refer to the dedicated chapter in the hardware manual for the boards of the 70xx series.

	External Clocki	External Clocking Mode					
Delay time	SINGLE	BURST_S	BURST_M				
† _{ckdly}	20 ns	30 ns	< 1 ns				
t _v	> 350 ns	> 150 ns	> 2.5 ns				
t _p	> 2.5 ns	> 2.5 ns	> 2.5 ns				
t _s	<u>≺</u> 3.0 ns	<u><</u> 3.0 ns	<u>≤</u> 3.0 ns				
t _{Vh}	<u><</u> 1.0 ns	<u><</u> 1.0 ns	<u><</u> 1.0 ns				



Order Informations

The card is delivered with 64 MByte on-board memory and supports standard mode (Scope), FIFO mode (streaming), Multiple Recording/Replay and Gated Sampling/Replay. Operating system drivers for Windows/Linux 32 bit and 64 bit, examples for C/C++, LabVIEW (Windows), MATLAB (Windows), LabWindows/CVI, Delphi, Visual Basic, Python and a Base license of the oscilloscope software SBench 6 are included. Drivers for other 3rd party products like VEE or DASYLab may be available on request.

One digital connecting cable Cab-d40-idc-100 is included in the delivery for every digital connection (each 16 channels).

<u>Versions</u>	Order no.	1 Bit	2 Bit	4 Bit	8 Bit	16 Bit	32 Bit
	MX.7005	125 MS/s	125 MS/s	125 MS/s	125 MS/s	125 MS/s	
	MX.7010	-	-	-	125 MS/s	125 MS/s	
	MX.7011	-	-	-	125 MS/s	125 MS/s	60 MS/s
<u>Memory</u>	Order no.	Option					
-	MX.7xxx-128M	Memory upg	grade to 128 <i>1</i>	∧B of total me	mory		
	MX.7xxx-up	Additional fe	ee for later me	mory upgrade			
<u>Cable</u>	Order no.	Option					
	Cab-d40-idc-100	Flat ribbon a	able 40 pole	FX2 for digital	connector to 2	2x20 pole IDC	C connector, 100 cm
	Cab-d40-d40-100	Flat ribbon cable 40 pole FX2 for digital connector to 40 pole digital FX2 connector, 100 cm					FX2 connector, 100 cm
<u>Software SBench6</u>	Order no.						
	SBenchó	Base version included in delivery. Supports standard mode for one card.					
	SBench6-Pro	Professional version for one card: FIFO mode, export/import, calculation functions					
	SBench6-Multi	Option multiple cards: Needs SBench6-Pro. Handles multiple synchronized cards in one system.					
	Volume Licenses	Please ask Spectrum for details.					

Technical changes and printing errors possible

SBench, digitizerNETBOX and generatorNETBOX are registered trademarks of Spectrum Instrumentation GmbH. Microsoft, Visual C++, Visual Basic, Windows, 98, Windows NT, Window 2000, Windows XP, Windows Vita, Windows 7, Windows 8 and Windows 10 are trademarks of paired trademarks of Microsoft Corporation. LabVIEW, DASVLab, Diadem and LabWindows/CVI are trademarks/registered trademarks of Microsoft Corporation. LabVIEW, DASVLab, Diadem and LabWindows/CVI are trademarks/registered trademarks of Microsoft Corporation. LabVIEW, DASVLab, Diadem and LabWindows/CVI are trademarks/registered trademarks of Microsoft Corporation. LabVIEW, DASVLab, Diadem and LabWindows/CVI are trademarks/registered trademarks of National Instruments Corporation. LabVIEW, DASVLab, Diadem and LabWindows/CVI are trademarks/registered trademarks of the Mathworks, Inc. Delphi and C++ Builder are trademarks/registered trademarks of Embarcadero Technologies, Inc. Keysight Technologies, Inc. FlexPro is a registered trademark of Weisang GmbH & Co. KG. PCIe, PCI Express and PCIX and PCISIG are trademarks of PCISIG. UX is a registered trademark of the DXI consortium. PICMG and CompactPCI are trademarks of the PCI Industrial Computation Manufacturers Group. Oracle and Java are registered trademarks of Oracle and/or its affiliates. Intel and Intel Xeon are trademarks of NVIDIA, CUDA, GeForce, Quadro and Tesla are trademarks of Avanced Micro Devices. NVIDIA, CUDA, GeForce, Quadro and Tesla are trademarks of NVIDIA Corporation.